

Zentralwerkstatt und
Ersatzteildepot
für ORION-Produkte


Schwalbe
Service & Versand GmbH

Postfach 10 10 26
63264 Dreieich
Max-Planck-Str. 20
63303 Dreieich

Ersatzteil-Bestellung




Tel.: (06103) 39 99-95 Fax.: (06103) 39 99-79

SERVICE MANUAL

Nachdruck bzw. Kopieren dieser Unterlagen ist grundsätzlich verboten!

Teil 1 **ORION** **VDR-4002**

DVD-RW RECORDER & VHS VIDEO CASSETTE RECORDER



ORIGINAL CHASSIS CODE A

Best. Nr. SM4002



Design and specifications are subject to change without notice.

IMPORTANT WARNING

CAUTION:

DVD PLAYER IS A CLASS 1 LASER PRODUCT. HOWEVER THIS PLAYER USES A VISIBLE LASER BEAM WHICH COULD CAUSE HAZARDOUS RADIATION EXPOSURE IF DIRECTED. BE SURE TO OPERATE THE PLAYER CORRECTLY AS INSTRUCTED.

THE FOLLOWING CAUTION LABEL IS LOCATED ON THE REAR PANEL OF THE PLAYER.



(Printed on the Rear Panel)

WHEN THIS PLAYER IS PLUGGED TO THE WALL OUTLET, DO NOT PLACE YOUR EYES CLOSE TO THE OPENING OF THE DISC TRAY AND OTHER OPENINGS TO LOOK INTO THE INSIDE OF THIS PLAYER.

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

DO NOT OPEN COVERS AND DO NOT REPAIR YOURSELF. REFER SERVICING TO QUALIFIED PERSONNEL.


SERVICING NOTICES ON CHECKING

1. KEEP THE NOTICES

As for the places which need special attentions, they are indicated with the labels or seals on the cabinet, chassis and parts. Make sure to keep the indications and notices in the operation manual.

2. USE THE DESIGNATED PARTS

The parts in this equipment have the specific characters of incombustibility and withstand voltage for safety. Therefore, the part which is replaced should be used the part which has the same character.

Especially as to the important parts for safety which is indicated in the circuit diagram or the table of parts as a  mark, the designated parts must be used.

3. PUT PARTS AND WIRES IN THE ORIGINAL POSITION AFTER ASSEMBLING OR WIRING

There are parts which use the insulation material such as a tube or tape for safety, or which are assembled in the condition that these do not contact with the printed board. The inside wiring is designed not to get closer to the pyrogenic parts and high voltage parts. Therefore, put these parts in the original positions.

4. PERFORM A SAFETY CHECK AFTER SERVICING

Confirm that the screws, parts and wiring which were removed in order to service are put in the original positions, or whether there are the portions which are deteriorated around the serviced places serviced or not. Check the insulation between the antenna terminal or external metal and the AC cord plug blades. And be sure the safety of that.

HOW TO ORDER PARTS

Please include the following informations when you order parts. (Particularly the CHASSIS CODE.)

1. MODEL NUMBER and CHASSIS CODE

The MODEL NUMBER can be found on the back of each product and the CHASSIS CODE can be found at the end of the SERIAL NUMBER.

2. PART NO. and DESCRIPTION

You can find it in your SERVICE MANUAL.

DISC REMOVAL METHOD AT NO POWER SUPPLY

1. Insert a fine rod (wire etc.) into the hole of the Front Cabinet as shown by the arrow. (Refer to Fig. 1)
The Tray is opened.
2. Draw the Tray.




Fig. 1

TAPE REMOVAL METHOD AT NO POWER SUPPLY

1. Remove the Top Cabinet, Front Cabinet and DVD Block. (Refer to item 1 of the **DISASSEMBLY INSTRUCTIONS**.)
2. Remove one screw of the Loading Motor from the insert hole for screw driver and remove the Loading Motor.
3. Rotate the Pinch Roller Cam in the direction of the arrow by hand to slacken the Video Tape. (Refer to Fig. 2)
4. Rotate the Clutch Ass'y either of the directions to wind the Video Tape in the Cassette Case.
5. Repeat the above step 3~4. Then take out the Video Cassette from the Deck Chassis. Be careful not to scratch on the tape.




Fig. 1




Fig. 2

PARENTAL CONTROL - RATING LEVEL 4 DIGIT PASSWORD CANCELLATION

If the stored 4 digit password in the Rating Level menu needs to be cancelled, please follow the steps below.

1. Turn Unit ON.
2. Press and hold the '7' key on the remote control unit.
3. Simultaneously press and hold the 'STOP' key on the front panel.
4. Hold both keys for more than 2 seconds.
5. The On Screen Display message 'PASSWORD UNLOCK' will appear.
6. The 4 digit password has now been cleared

NB: No indications on the screen when the Parental Lock is setting.

TRAY LOCK

Tray cannot be opened by setting the Tray Lock, please follow the steps below.

1. Turn Unit ON.
2. Press and hold the '0' key on the remote control unit.
3. Simultaneously press and hold the 'STOP' key on the front panel.
4. Hold both keys for more than 2 seconds.
5. Press the OPEN/CLOSE key on the front panel to check the Tray Lock setting.

NB: No indications on the screen when the Tray Lock is setting.

To unlock the Tray Lock, please follow the steps below.

1. Turn Unit ON.
2. Simultaneously press and hold the 'PLAY' button and 'CH UP' button on the front panel.
3. Hold both keys for more than 2 second.
4. The On Screen Display message 'FACTORY INITIALIZE' will appear.
5. The Tray Lock has now been cleared.
6. Turn Unit OFF.

NB: The above procedure will reset ALL of the player's settings to the default factory state.

CONTENTS

IMPORTANT WARNING	A1-1
SERVICING NOTICES ON CHECKING	A1-1
HOW TO ORDER PARTS	A1-1
DISC REMOVAL METHOD AT NO POWER SUPPLY	A1-2
TAPE REMOVAL METHOD AT NO POWER SUPPLY	A1-2
PARENTAL CONTROL-RATING LEVEL	A1-2
TRAY LOCK	A1-3
CONTENTS	A2-1
GENERAL SPECIFICATIONS	A3-1~A3-8
DISASSEMBLY INSTRUCTIONS	
1. REMOVAL OF MECHANICAL PARTS AND P. C. BOARDS	B1-1, B1-2
2. REMOVAL OF VCR DECK PARTS	B2-1~B2-6
3. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC	B3-1, B3-2
KEY TO ABBREVIATIONS	C1-1, C1-2
SERVICE MODE LIST	C2-1
PREVENTIVE CHECKS AND SERVICE INTERVALS	C3-1, C3-2
WHEN REPLACING EEPROM (MEMORY) IC	C4-1
SERVICING FIXTURES AND TOOLS	D1-1
PREPARATION FOR SERVICING	D1-1
MECHANICAL ADJUSTMENTS	D2-1~D2-4
ELECTRICAL ADJUSTMENTS	D3-1, D3-2
BLOCK DIAGRAMS	
MPEG	E-1, E-2
Y/C/AUDIO/HEAD AMP	E-3, E-4
SYSTEM CONTROL	E-5, E-6
REGULATOR	E-7, E-8
OPERATION/DISPLAY	E-9, E-10
AV IN/OUT/TUNER/Hi-Fi	E-11, E-12
21PIN IN/OUT	E-13, E-14
POWER	E-15, E-16
PRINTED CIRCUIT BOARDS	
DVD/HD MPEG	F-1, F-2
VCR	F-3~F-6
POWER/OPERATION	F-7, F-8
SCHEMATIC DIAGRAMS	
AV ENCODER	G-1, G-2
MPEG	G-3, G-4
MEMORY	G-5, G-6
ATAPI	G-7, G-8
FPGA	G-9, G-10
VIDEO DECODER	G-11, G-12
AUDIO ADC	G-13, G-14
AUDIO DAC	G-15, G-16
Y/C/AUDIO/HEAD AMP	G-17, G-18
SYSCON/SERVO/TIMER	G-19, G-20
AV IN/OUT	G-21, G-22
21PIN IN/OUT	G-23, G-24
REGULATOR	G-25, G-26
DISPLAY	G-27, G-28
Hi-Fi	G-29, G-30
POWER	G-31, G-32
OPERATION/LED	G-33, G-34
INTERCONNECTION DIAGRAM	G-35, G-36
WAVEFORMS	H-1~H-4
MECHANICAL EXPLODED VIEW	I1-1
CHASSIS EXPLODED VIEWS	I2-1, I2-2
MECHANICAL REPLACEMENT PARTS LIST	J1-1
CHASSIS REPLACEMENT PARTS LIST	J2-1
ELECTRICAL REPLACEMENT PARTS LIST	J3-1~J3-3

GENERAL SPECIFICATIONS

G-1	Outline of the product		DVD-R/-RW Video Recorder & VHS Player/Recorder
G-2	DVD System	Color System	PAL
		Disc Format	DVD-R/-RW
		Rec	DVD-R/-RW, DVD-Video, CD-DA, CD-R/-RW, VIDEO CD, SVCD
		Play	
		Disc Diameter	120 mm, 80 mm
		Deck	Front Disc Loading
		Disc Loading System	3 Motors
		Motor	1-Lens 2-Beams System
		Pick up	
		Rec Time (Aprox.)	1 hour at 10Mbps
		at 4.7GB Disc	2 hour at 5Mbps
		XP	4 hour at 2.5Mbps
		SP	6 hour at 1.6Mbps
		LP	
		SLP	
		Playback time (Max)	DVD 1-Layer 135min (4.7GB)
			DVD 2-Layer 245min (8.5GB)
			CD 74min
			VIDEO CD 74min
		Search speed	Fwd 4 step
			2-45 times (DVD, VIDEO CD)
		Actual	4-40 times (CD)
			Rev 4 step
		Actual	2-45 times (DVD, VIDEO CD)
			4-40 times (CD)
		Slow speed	Fwd 1/8-1/2 times
		Actual	--
			Rev --
		Actual	--
G-3	VCR System	System	VHS Player / Recorder
		Video System	PAL
		Hi-Fi STEREO	Yes
		NTSC PB(PAL60Hz)	Yes
		Deck	OVD-7
		DECK	Front
		Loading System	3
		Motor	
		Heads	Video Head 4Head
			FM Audio Head 2Head
			Audio / Control Mono / Yes
			Erase (Full Track Erase) Yes
		Tape	Rec SP/LP
		Speed	NTSC -
			Play SP/LP
			NTSC SP
		Fast Forward / Rewind Time (Approx.) at 25oC	FF:1'12" / REW:1'12"
		with Cassette	E-180
		Forward/Reverse	NTSC or PAL-M SP/LP = 3x,5x
		Picture Search	PAL or SECAM SP/LP=5x,7x / 7x, 13x
		Frame Advance	Yes
		Slow Speed	1/5, 1/10, 1/30
G-4	Tuning System	Broadcasting System	CCIR System BG
		Tuner and	1Tuner
		Receive CH	System
			Destination Oscar (w/HYPER)
			Tuning System F-Synth
			Input Impedance VHF/UHF 75 ohm
			CH Coverage E2-E4,X-Z+2,S1-S10,E5-E12,S11-S41, E21-E69
		Intermediate	Picture (FP) 38.9 MHz
		Frequency	Sound (FS) 33.4 MHz
			FP-FS 5.5 MHz
		Auto Tuning Method	C.C.I.R CH PLAN
		Auto Guide Ch Area	-
		Preset CH	80 CH
		RF Converter Output	-
		Channel	-
		Level/Impedance	-
		Sound Selector	-
		Stereo/Dual TV Sound	G.ST/NICAM DUAL
		Tuner Sound Muting	Yes

GENERAL SPECIFICATIONS

G-5	Power	Power Source	AC	230V 50Hz
			DC	-
		Power Consumption	Stand by (FIP Off)	33 W at 230V 50Hz
			Stand by (FIP On)	5.5 W at 230V 50Hz
			Per Year	6 W at 230V 50Hz
G-6	Regulation	Protector	Power Fuse	Yes
			Safety Circuit	Yes
			IC Protector(Micro Fuse)	No
			Safety	CE
G-7	Temperature		Radiation	CE
			Laser	-
			Operation	50C - 350C
G-8	Operating Humidity		Storage	-200C - 600C
				Less than 80% RH
G-9	Signal	Video Signal	Output Level	1 V p-p / 75 ohm (DVD, VCR)
			S/N Ratio (Weighted)	65 dB (DVD-Video) 53 dB (VCR)
			Horizontal Resolution	500 Lines (DVD-Video) 240 Lines (VCR)
			Output Level	0.7V p-p/75 ohm
		RGB Signal		
		Audio Signal	Input Level Microphone	--
			Input Level Line	-3.8 dBm / 50k ohm (VCR, 0dBm=0.775Vrms)
				-3.8 dBm / 1k ohm (VCR, 0dBm=0.775Vrms)
			Output Level Line	-12dB / 1k ohm (DVD, -20dBFS 0dBFS=2.0Vrms)
			Digital Output Level	0.5 V p-p / 75 ohm (DVD)
			S/N Ratio at (Weighted)	90dB (DVD-Video), 42dB (VCR at SP)
			Harmonic Distortion (1KHz) Typical	0.06% (DVD-Video), 1.5% (VCR at SP)
			Frequency Response : DVD Mode at DVD	4 Hz - 22 kHz
			DVD Mode at VIDEO CD	4 Hz - 20 kHz
			DVD Mode at SVCD	4 Hz - 20 kHz
			DVD Mode at CD	4 Hz - 20 kHz
			VCR Mode at SP	100 Hz - 10 kHz
			VCR Mode at LP	100 Hz - 5 kHz
			VCR Mode at SLP	-
		Hi-Fi Audio Signal	Dynamic Range : More than	75dB
			Frequency Response	20Hz ~20kHz
			Wow And Flutter : Less than	0.01 %Wrms
			Channel Separation : More than	60 dB
			Harmonic Distortion : Less than	0.01

GENERAL SPECIFICATIONS

G-10	On Screen Display (DVD)	Menu		Yes
		Menu Type		Character
		Setup	Timer Rec Set	Yes
			System Setup	Yes
			Language	Yes
			OSD Language	Yes
			DVD Menu	Yes
			Audio	Yes
			Subtitle	Yes
			Parental	Yes
			Password Lock/Unlock	Yes
			Rating Level	Yes
			Clock	Yes
			Clock Set	Yes
			Auto Clock(Auto Time)	No
			Disc Setup	Yes
			New Disc Format	Yes
			Reformat as DVD VR	Yes
			Reformat as DVD Video	Yes
			Finalize	Yes
			Protect Disc	Yes
			Undo Finalize	Yes
			Other	Yes
			Dimmer	Yes
			Display/Call On/Off	Yes
		AV Setup		Yes
			Video	Yes
			TV Screen	Yes
			Still Mode	Yes
			No Noise Background	Yes
			Brightness	Yes
			DVD Output	Yes
			AV2	Yes
			AV3 Input	Yes
			Color System	No
			Audio	Yes
			DRC (Dynamic Range Control)	Yes
			Virtual Surround (Spatializer(N-2-2))	Yes
			External Audio Input Selection	Yes
			NICAM	Yes
			DOLBY DIGITAL OUTPUT	Yes
		Rec Setup		Yes
			Initial Rec To	Yes
			Initial Rec Mode	Yes
			Auto Chapter	Yes
			Index Picture	Yes
			Bilingual Recording	Yes
		CH Setup		Yes
			CH tuning	Yes
			CH	Yes
			Skip	Yes
			Decoder	Yes
			Move	Yes
			Tuning System	No
			Tuning	Yes
			Auto Tuning	Yes
		Other	JPEG Interval	Yes

GENERAL SPECIFICATIONS

G-10	Title Menu (VR Mode)		Yes	
		Chapter		
		Add Chapter Mark	Yes	
		Combine Chapters	Yes	
		Play	Yes	
		Rename Title	Yes	
		Title Protect		No
		Thumb Nail Setting		No
		Delete Title	Yes	
		Title Combine		No
		Title Divide		No
		Edit Title	Yes	
		Rename Disc	Yes	
		Genre		No
		Play List		
		Play	Yes	
		Chapter		No
		Rename Title	Yes	
		Delete Title	Yes	
		Title Combine	Yes	
		Title Divide		No
		Edit Title	Yes	
	Title Menu (Video Mode)		Yes	
		Chapter		No
		Chapter Mark Add		No
		Chapter Mark Delete		No
		Play	Yes	
		Title Name		No
		Title Protect		No
		Thumb Nail Setting		No
		Title Delete		No
		Title Combine		No
		Title Divide		No
		Edit Title		No
		Rename Disc	Yes	
		Genre		No
		Play List		No
		Chapter		No
		Title Name		No
		Title Delete		No
		Title Combine		No
		Title Divide		No
		Cut		No
	Dubbing	DVD >>> VCR	Yes	
		VCR >>> DVD	Yes	
		Disc Information	Yes	
		Disc Type	Yes	
		Disc Remain Time	Yes	
		Open	Yes	
		Close		No
		No disc	Yes	
		Reading	Yes	
		Play	Yes	
		Pause/Still	Yes	
		Stop	Yes	
		Prohibit Mark	Yes	
		Step	Yes	
		Skip (>>)	Yes	
		Skip (<<)	Yes	
		Random	Yes	(CD, VIDEO CD, SVCD)
		Repeat	Yes	
		Slow+ ##	Yes	
		Slow- ##		No
		Search+ ##	Yes	
		Search- ##	Yes	
		Time Search (Jump)	Yes	
		Resume	Yes	
		Title No.	Yes	
		Chapter No.	Yes	
		Track No.	Yes	
		Time	Yes	
		Sub Title No.	Yes	
		Angle No.	Yes	
		Vocal On/Off	Yes	
		Audio No.	Yes	
		Audio Stereo L/R	Yes	(VIDEO CD, SVCD)
		Zoom	Yes	
		Marker No.		No
		Program Play Back	Yes	(CD, MP3, WMA, SVCD, VIDEO CD)
		MP3 / WMA / JPEG	Folder Name	Yes
			File Name	Yes
			File No	Yes
			Time	Yes
			Track No	Yes
		Progressive Scan Out On/Off		No

GENERAL SPECIFICATIONS

	On Screen Display (VCR)	Menu		No
		Menu Type	-	
		Play/Stop/FF/Rew/Rec/OTR (ITR)/T-Rec/Pause/Eject/Tape In (Symbol Mark)	Yes	
		CH/AV (LINE)	Yes	
		Clock	Yes	
		Repeat	Yes	
		Tape Counter	Yes	
		Index	Yes	
		Tape Speed	Yes	
		Decoder		No
		Sound	Yes	
		Manual Tracking (Bar Setting)	Yes	
		Hi-Fi	Yes	
		Zero Return	Yes	
		OTPB		No
G-11	OSD Language	DVD OSD	English, French, Spanish, German, Italian	
		VCR OSD	English, French, Spanish, German, Italian	
G-12	Clock, Timer and Timer Back-up	Calendar	1990/1/1 ~ 2081/12/31	
		Timer Events	8Program / 1Month	
		One Touch Recording Max Time	6 hours	
		OTPB Valid Time		
		Timer Back-up (at Power Off Mode)	30 min	
G-13	Display	Display	Yes	
		Display Type	6Digit Fluorescent Indicator	
		Clock	Yes (24h)	
		AM		No
		PM		No
		Counter	VCR	Yes (hour: min: sec)
			DVD	Yes (hour: min: sec)
			CD	Yes (min: sec)
		TV/VCR	Yes	
		CD	Yes	
		DVD	Yes	
		VR Mode	Yes	
		Video Mode		
		DVD-R	Yes	
		DVD-RW	Yes	
		DVD+R		
		DVD+RW		
		DVD-RAM		
		Disc In	Yes	
		Tape In	Yes	
		T-Rec	Yes	
		XP	Yes	
		SP	Yes	
		LP	Yes	
		SLP	Yes	
		EP		
		VP		
		Counter Remain		
		Chapter		
		Title		
		Track No.	Yes	
		Repeat (A-B/All)		
		Play (VCR Side)	Yes	
		Pause / Still (VCR Side)	Yes	
		Rec (VCR Side)	Yes	
		Play (DVD Side)	Yes	
		Pause / Still / Step (DVD Side)	Yes	
		Rec (DVD Side)	Yes	
		RF Output CH		
		Eject	Yes	
		Stop		
		FF / Cue		
		REW / Review		
		OTR (ITR)		
		Hi-Fi		
		CH/AV	Yes	
		BS		
		CATV		
		Progressive Scan Out		
		Under processing	Yes	
		PBC (Play Back Control)		

GENERAL SPECIFICATIONS

G-14	Remote Control	Unit	RC-JJ
		Glow in Dark Remocon	No
		LCD	No
		Format	NEC
		Custom Code	71-8EH
		Power Source	3V
		Voltage (D.C)	UM-4 x 2 pcs
		UM size x pcs	49 Keys
		Total Keys	49 Keys
		Keys	POWER
			Yes
		EJECT	Yes
		OPEN / CLOSE	Yes
		DVD / VCR	Yes
		1	Yes
		2	Yes
		3	Yes
		4	Yes
		5	Yes
		6	Yes
		7	Yes
		8	Yes
		9	Yes
		0	Yes
		0 / 10	No
		11	No
		12	No
		T-REC	Yes
		INPUT SELECT	Yes
		CLEAR / CANCEL	Yes
		RETURN	Yes
		DISPLAY / CALL	Yes
		TOP MENU / TITLE LIST	Yes
		UP / CH+	Yes
		DOWN / CH-	Yes
		LEFT / TRACKING-	Yes
		RIGHT / TRACKING+	Yes
		SELECT / ENTER	Yes
		DVD MENU	Yes
		SETUP	Yes
		STOP	Yes
		PLAY	Yes
		PAUSE / STILL / STEP	Yes
		[<<SKIP / INDEX-	Yes
		<<SEARCH / REW	Yes
		SEARCH>> / F.FWD	Yes
		SKIP>> / INDEX+	Yes
		ONE TOUCH REPEAT	Yes
		CM SKIP	Yes
		<<SLOW	No
		SLOW>>	Yes
		REC / OTR	Yes
		REC MODE / SPEED	Yes
		DUBBING	Yes
		AUDIO / AUDIO SELECT	Yes
		MARKER	No
		ZOOM	Yes
		REPEAT A-B	Yes
		ZERO RETURN	Yes
		ANGLE / COUNTER RESET	Yes
		SUB TITLE / ATR	Yes
		PLAY MODE / REPEAT	Yes
		CLOCK / COUNTER	Yes
		CHAPTER MARK	No
		NAVI MARK	No
		TV / VCR	Yes
		PROGRESSIVE	No

GENERAL SPECIFICATIONS

G-15	Features (DVD & VCR)	Auto Power Off		No
		CM Skip (30sec x 6 Times)	Yes	
		Copy (Tape to Disc, Disc to Tape)	Yes (By Conditioning)	
		VIDEO PLUS+ (SHOWVIEW, G-CODE)		No
		Auto Set Up (CH Auto Set Up/ Auto Clock)		No
		ATS		No
		PDC		No
		VPS		No
		Energy Star		No
		Analog BS		No
		Power On Memory		No
	Features (DVD)	Parental Lock	Yes	
		Echo		No
		Mic Mixing		No
		DV Rec		No
		Timeshift Playback		No
		Video CD Playback	Yes	
		SVCD Playback	Yes	
		Overlay Graphics And Text		No
		Command List		No
		Entry Point Jump		No
		MP3 Playback	Yes	
		WMA Playback	Yes	
		JPEG Playback	Yes	
		Progressive Scan Out		No
		Digital Out	(Dolby Digital)	Yes
			(MPEG)	Yes
			(PCM)	Yes
			(DTS)	Yes
		Down Mix Out	(Dolby Digital)	Yes
			(DTS)	No
		Spatializer (N-2-2)	Yes	
		Screen Saver		No
		Auto Stop		No
	Features (VCR)	Tray Lock	Yes	
		One Touch Repeat	Yes	
		Audio DAC	192kHz / 24bit	
		Auto Head Cleaning	Yes	
		Auto Tracking	Yes	
		Index Search	Yes	
		HQ (VHS Standard High Quality)	Yes	
		Auto Power On, Auto Play, Auto Rewind, Auto Eject	Yes	
		Forward/Reverse Picture Search	Yes	
		SQPB (PAL SP Mode Only)		No
		Rec End Search		No
		CS Easy		No
G-16	Accessories	Owner's Manual	Yes	
		Language	German	
		w/Guarantee Card	Yes	
		Remote Control Unit	Yes	
		Dew Caution Sheet		No
		Battery	Yes	
		UM size x pcs	UM-4 x 2 pcs	
		Blank DVD-RW DISC (4.7GB)	Yes	
		Blank DVD-R DISC (4.7GB)		No
		Tape Rewinder		No
		Safety Tip		No
		Toll Free Insert Sheet		No
		Quick Set-Up Sheet		No (1st O/R Lot)
			Yes (From 2nd Lot)	
		Information Sheet	Yes	
		75 Ohm Coaxial Cable	Yes (0.9m)	
		type	Double shield	
		U/V Mixer		No
		DC Car Cord (Center+)		No
		Guarantee Card		No
		Warning Sheet		No
		Circuit Diagram		No
		Antenna Change Plug		No
		Service Facility List		No
		Important Safeguard		No
		Dew/AHC Caution Sheet		No
		AC Plug Adapter		No
		AC Cord		No
		AV Cord (2Pin-1Pin)		No
		Registration Card		No
		21pin Cable (Double Shield)	Yes	
		300 ohm to 75 ohm Antenna Adapter		No

GENERAL SPECIFICATIONS

G-17	Interface	Switch	Front	Power	Yes	
				Play	Yes	
				Eject (VCR)	Yes	
				Stop	Yes	
				Rec / OTR	Yes	
				Open / Close (DVD)	Yes	
				CH +	Yes	
				CH -	Yes	
				FF / Search(>>)	Yes	
				Rew / Search(<<)	Yes	
				Still / Pause	No	
				Shuttle (Search / REV / FWD)	No	
				DVD / VCR	Yes	
			Rear	Main Power SW	No	
				S-Video / Component Video Selector	No	
				RF Out (Slide SW)	No	
				Main Power SW	No	
		Volume	Phones Volume	No		
			Mic Volume	No		
			Echo Volume	No		
		Terminals	Front	Video In	RCA x1 (Yellow) S-Video x 1 (DVD Rec Only)	
				Audio In	RCA x 2 (Stereo, White/Red)	
				DV In (IEEE1394)	No	
					No	
			Rear	Video Output	No	
				Audio Output	RCA x 2 (Stereo, White/Red) Coaxial x 1 (Digital Audio, DVD Signal Only)	
				Video In	No	
				Audio In	No	
				Optical Digital Audio Out	No	
				Euro Scart	2SCART	
				Ext Speaker	No	
				VHF/UHF Antenna Input/Output	DIN Type	
				AC Inlet	No	
			Indicator	LED	Power	No
					Rec	No
					T-Rec	No
					TV/VCR	No
					DVD	Yes (GREEN)
					VCR	Yes (AMBER)
					Surround	No
					Level Meter	No
G-18	Set Size		Approx.	W x D x H (mm)	430 x 311.5 x 99	
G-19	Weight			Net (Approx.)	5.5 kg (12.1 lbs)	
				Gross (Approx.)	6.5 kg (14.3 lbs)	
G-20	Carton	Master Carton			No	
			Content	--- Sets		
			Material	--- / ---		
			Dimensions W x D x H (mm)	---		
			Description of Origin	---		
		Gift Box		Yes		
			Material	Single/Full Color		
			W/Color Photo Label	No		
			Dimensions W x D x H (mm)	500 x 430 x 180		
			Design	As Per BUYER's		
			Description of Origin	No		
		Drop Test	Natural Dropping At		1 Corner / 3 Edges / 6 Surfaces	
				Height (cm)	80 cm	
			Container Stuffing		1,623 Sets/40' container	
G-21	Material		Cabinet Front	PS 94HB		
		PCB	Non-Halogen Demand	No		
			Eyelet Demand	No		
G-22	Environment	Pb Free		Lead-free Solder	No	
				Other	No	
		Cd Free			No	

DISASSEMBLY INSTRUCTIONS

1. REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS

1-1: TOP CABINET AND FRONT CABINET (Refer to Fig. 1-1)

1. Remove the 5 screws ①.
2. Remove the Top Cabinet in the direction of arrow (A).
3. Disconnect the following connector: (CP681).
4. Unlock the 9 supports ②.
5. Remove the Front Cabinet in the direction of arrow (B).
6. Remove the 3 screws ③.
7. Remove the Operation PCB in the direction of arrow (C).




Fig. 1-1

1-2: FLAP (Refer to Fig. 1-2)

1. Open Flap to 90° and flex in direction of arrow (A), at the same time slide in direction of arrow (B).
2. Then lift in direction of arrow (C).




Fig. 1-2

1-3: DECK CD AND DVD/HD MPEG PCB (Refer to Fig. 1-3)

1. Remove the 6 screws ①.
2. Disconnect the following connectors: (CP504, CP1703, CP8301, CP8302, CP8303).
3. Remove the Deck CD Block in the direction of arrow (A).
4. Remove the 4 screws ②.
5. Remove the MPEG Shield in the direction of arrow (B).
6. Disconnect the following connector: (CP4006).
7. Remove the DVD/HD MPEG PCB in the direction of arrow (C).
8. Remove the 2 screws ③.
9. Remove the DVD Angle (L) in the direction of arrow (D).
10. Remove the 2 screws ④.
11. Remove the DVD Angle (R) in the direction of arrow (E).





Fig. 1-3

DISASSEMBLY INSTRUCTIONS


1-4: POWER PCB (Refer to Fig. 1-4)

1. Remove the 2 screws ①.
2. Disconnect the following connector: (CP506).
3. Remove the Fan Motor in the direction of arrow (A).
4. Remove the 3 screws ②.
5. Disconnect the following connector: (CP1701).
6. Remove the Power PCB in the direction of arrow (B).



1-6: VCR PCB (Refer to Fig. 1-6)

1. Remove the screw ①.
2. Remove the screw ②.
3. Remove the 2 screws ③.
4. Remove the Jack Shield.
5. Remove the VCR PCB in the direction of arrow.




1-5: VCR DECK (Refer to Fig. 1-5)

NOTE

Do not remove the cable at the FE Head section. The FE Head may be damaged if you remove the cable by force.

1. Unlock the 2 supports ① and remove the Top Holder.
2. Remove the screw ②.
3. Remove the FE Head.
4. Move the Cassette Holder Ass'y to the back side.
5. Remove the 3 screws ③.
6. Disconnect the following connectors:
(CP101, CP102, CP3001).
7. Remove the AC Head Cover and VCR Deck in the direction of arrow.



DISASSEMBLY INSTRUCTIONS


2. REMOVAL OF VCR DECK PARTS

2-1: TOP BRACKET (Refer to Fig. 2-1)

1. Extend the 2 supports ①.
2. Slide the 2 supports ② and remove the Top Bracket.


NOTE

1. After the installation of the Top Bracket, bend the support ① so that the Top Bracket is fixed.




2-2: CASSETTE HOLDER ASS'Y (Refer to Fig. 2-2)

1. Move the Cassette Holder Ass'y to the front side.
2. Push the Locker R to remove the Cassette Side R.
3. Remove the Cassette Side L.




2-3: CASSETTE SIDE L/R (Refer to Fig. 2-3-A)

1. Remove the Locker Spring.
2. Unlock the 4 supports ① and then remove the Cassette Side L/R.
3. Unlock the support ② and then remove the Locker R.




NOTE

1. In case of the Locker R installation, check if the one position of Fig.2-3-B are correctly locked.
2. When you install the Cassette Side R, be sure to move the Locker R after installing.




2-4: LINK UNIT (Refer to Fig. 2-4)

1. Set the Link Unit to the Eject position.
2. Unlock the support ①.
3. Remove the (A) side of the Link Unit first, then remove the (B) side.



2-5: LINK LEVER/FLAP LEVER (Refer to Fig. 2-5)


1. Extend the support ①.
2. Remove the Link Lever.
3. Remove the Flap Lever.



DISASSEMBLY INSTRUCTIONS




2-6: LOADING MOTOR/WORM (Refer to Fig. 2-6-A)

1. Remove the screw ①.
2. Remove the Loading Motor.
3. Remove the Worm.





NOTE

1. In case of the Worm installation, check if the value of the Fig. 2-6-B is correct.
2. In case of the Loading Motor installation, hook the wire on the Cassette Opener as shown Fig. 2-6-C.
3. When installing the wires between Capstan DD Unit and Loading Motor, connect them correctly as shown Fig. 2-6-D.






2-7: TENSION ASS'Y (Refer to Fig. 2-7-B)

1. Turn the Pinch Roller Cam clockwise so that the Tension Holder hook is set to the position of Fig. 2-7-A to move the Tension Arm Ass'y.
2. Remove the Tension Spring.
3. Unlock the 2 supports ① and remove the Tension Band.
4. Unlock the support ② and remove the Tension Arm Ass'y.
5. Unlock the support ③ and remove the Tension Connect.
6. Float the hook ④ and turn it clockwise then remove the Tension Holder.



NOTE


1. In case of the Tension Band installation, note the direction of the installation. (Refer to Fig. 2-7-C)
2. In case of the Tension Band installation, install correctly as Fig. 2-7-D.
3. In case of the Tension Connect installation, install as the circled section of Fig. 2-7-E.



DISASSEMBLY INSTRUCTIONS


2-8: T BRAKE ARM/T BRAKE BAND (Refer to Fig. 2-8-A)

1. Remove the T Brake Spring.
2. Turn the T Brake Arm clockwise and bend the hook section to remove it.
3. Unlock the 2 supports ① and remove the T Brake Band.



NOTE

1. In case of the T Brake Band installation, install correctly as Fig. 2-8-B.




2-9: S REEL/T REEL/IDLER ARM ASS'Y/IDLER GEAR (Refer to Fig. 2-9-A)

1. Remove the S Reel and T Reel.
2. Remove the 2 Polyslider Washers ①.
3. Remove the Idler Arm Ass'y and Idler Gear.



NOTE

1. Take care not to damage the gears of the S Reel and T Reel.
2. The Polyslider Washer may be remained on the back of the reel.
3. Take care not to damage the shaft.
4. Do not touch the section "A" of S Reel and T Reel. (Use gloves.) (Refer to Fig. 2-9-A) Do not adhere the stains on it.
5. When you install the reel, clean the shaft and grease it (FG-84M). (If you do not grease, noise may be heard in FF/REW mode.)
6. After installing the reel, adjust the height of the reel. (Refer to MECHANICAL ADJUSTMENT)



NOTE


1. In case of the S Reel and T Reel installation, check if the correct parts are installed. (Refer to Fig. 2-9-B)
2. In case of the Idler Arm Ass'y installation, install correctly as Fig. 2-9-C. And also set it so that the section "B" of Fig. 2-9-A is placed under the Main Chassis tab.



DISASSEMBLY INSTRUCTIONS


2-10: CASSETTE OPENER/PINCH ROLLER BLOCK/ P5 ARM ASS'Y (Refer to Fig. 2-10-A)

1. Unlock the support ① and remove the Cassette Opener.
2. Remove the Pinch Roller Block and P5 Arm Ass'y.



NOTE

1. Do not touch the Pinch Roller. (Use gloves.)
2. In case of the Pinch Roller Block and the Pinch Roller Cam installation, install correctly as Fig. 2-10-B.




2-11: A/C HEAD (Refer to Fig. 2-11-A)


1. Remove the screw ①.
2. Remove the A/C Head Base.
3. Remove the 3 screws ②.
4. Remove the A/C Head and A/C Head Spring.

NOTE

1. Do not touch the A/C Head. (Use gloves.)
2. When you install the A/C Head Spring, install as shown in Fig. 2-11-B.
3. When you install the A/C Head, tighten the screw (1) first, then tighten the screw (2), finally tighten the screw (3).




• Screw Torque: $5 \pm 0.5 \text{ kgf}\cdot\text{cm}$ (Screw ①)



2-12: FE HEAD (RECORDER ONLY) (Refer to Fig. 2-12)

1. Remove the screw ①.
2. Remove the FE Head.




- Screw Torque: $5 \pm 0.5 \text{ kgf}\cdot\text{cm}$
- The FE Head is not installed on the Video Cassette Player.

2-13: AHC ASS'Y/CYLINDER UNIT ASS'Y (Refer to Fig. 2-13)

1. Unlock the support ① and remove the AHC Ass'y.
2. Disconnect the following connector: (CD2001)
3. Remove the 3 screws ②.
4. Remove the Cylinder Unit Ass'y.

NOTE

1. When you install the Cylinder Unit Ass'y, tighten the screws from (1) to (3) in order while pulling the Ass'y toward the left front direction.



• Screw Torque: $3 \pm 0.5 \text{ kgf}\cdot\text{cm}$

DISASSEMBLY INSTRUCTIONS

2-14: CAPSTAN DD UNIT (Refer to Fig. 2-14)

1. Remove the Capstan Belt.
2. Remove the screw ①.
3. Remove the Capstan Holder.
4. Remove the 3 screws ②.
5. Remove the Capstan DD Unit.





Fig. 2-14


2-15: MAIN CAM/PINCH ROLLER CAM/JOINT GEAR (Refer to Fig. 2-15-A)

1. Remove the E-Ring ①, then remove the Main Cam.
2. Remove the E-Ring ②, then remove the Pinch Roller Cam and Joint Gear.




NOTE

1. In case of the Pinch Roller Cam and Main Cam installation, install them as the circled section of Fig. 2-15-B so that the each markers are met. (Refer to Fig. 2-15-B)




2-16: LOADING GEAR S/T UNIT (Refer to Fig. 2-16-A)

1. Remove the E-Ring ① and remove the Main Loading Gear.
2. Remove the Main Rod, Tension Lever, Loading Arm S Unit and Loading Arm T Unit.



NOTE

1. When you install the Loading Arm S Unit, Loading Arm T Unit and Main Loading Gear, align each marker. (Refer to Fig. 2-16-B)



DISASSEMBLY INSTRUCTIONS

2-17: CLUTCH ASS'Y/RING SPRING/CLUTCH LEVER/ CLUTCH GEAR (Refer to Fig. 2-17-A)

1. Remove the Polyslider Washer ①.
2. Remove the Clutch Ass'y and Ring Spring.
3. Remove the Clutch Lever.
4. Remove the Coupling Gear, Coupling Spring and Clutch Gear.




Fig. 2-17-A

NOTE

1. In case of the Clutch Ass'y installation, install it with inserting the spring of the Clutch Ass'y into the dent of the Coupling Gear. (Refer to Fig. 2-17-B)




Fig. 2-17-B

2-18: CASSETTE GUIDE POST/INCLINED BASE S/T UNIT/P4 CAP/LED REFLECTOR (Refer to Fig. 2-18-A)

1. Remove the P4 Cap.
2. Unlock the support ① and remove the Cassette Guide Post.
3. Remove the Inclined Base S/T Unit.
4. Remove the screw ②.
5. Remove the LED Reflector.




Fig. 2-18-A

NOTE

1. Do not touch the roller of Guide Roller.
2. In case of the P4 Cap installation, install it with parallel for "A" and "B" of Fig. 2-18-B.
3. In case of the Cassette Guide Post installation, install correctly as the circled section of Fig. 2-18-C.




Fig. 2-18-B




Fig. 2-18-C

DISASSEMBLY INSTRUCTIONS


3. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC

REMOVAL

1. Put the Masking Tape (cotton tape) around the Flat Package IC to protect other parts from any damage. (Refer to Fig. 3-1.)

NOTE


Masking is carried out on all the parts located within 10 mm distance from IC leads.



2. Heat the IC leads using a blower type IC desoldering machine. (Refer to Fig. 3-2.)

NOTE


Do not add the rotating and the back and forth directions force on the IC, until IC can move back and forth easily after desoldering the IC leads completely.



3. When IC starts moving back and forth easily after desoldering completely, pickup the corner of the IC using a tweezers and remove the IC by moving with the IC desoldering machine. (Refer to Fig. 3-3.)

NOTE


Some ICs on the PCB are affixed with glue, so be careful not to break or damage the foil of each IC leads or solder lands under the IC when removing it.



4. Peel off the Masking Tape.
5. Absorb the solder left on the pattern using the Braided Shield Wire. (Refer to Fig. 3-4.)

NOTE


Do not move the Braided Shield Wire in the vertical direction towards the IC pattern.




DISASSEMBLY INSTRUCTIONS

INSTALLATION

1. Take care of the polarity of new IC and then install the new IC fitting on the printed circuit pattern. Then solder each lead on the diagonal positions of IC temporarily. (Refer to Fig. 3-5.)




2. Supply the solder from the upper position of IC leads sliding to the lower position of the IC leads. (Refer to Fig. 3-6.)




3. Absorb the solder left on the lead using the Braided Shield Wire. (Refer to Fig. 3-7.)

NOTE

Do not absorb the solder to excess.



4. When bridge-soldering between terminals and/or the soldering amount are not enough, resolder using a Thin-tip Soldering Iron. (Refer to Fig. 3-8.)



5. Finally, confirm the soldering status on four sides of the IC using a magnifying glass.

Confirm that no abnormality is found on the soldering position and installation position of the parts around the IC. If some abnormality is found, correct by resoldering.

NOTE

When the IC leads are bent during soldering and/or repairing, do not repair the bending of leads. If the bending of leads are repaired, the pattern may be damaged. So, always be sure to replace the IC in this case.

KEY TO ABBREVIATIONS

A	A/C	: Audio/Control	H.SW	: Head Switch
	ACC	: Automatic Color Control	Hz	: Hertz
	AE	: Audio Erase	I IC	: Integrated Circuit
	AFC	: Automatic Frequency Control	IF	: Intermediate Frequency
	AFT	: Automatic Fine Tuning	IND	: Indicator
	AFT DET	: Automatic Fine Tuning Detect	INV	: Inverter
	AGC	: Automatic Gain Control	K KIL	: Killer
	AMP	: Amplifier	L L	: Left
	ANT	: Antenna	LED	: Light Emitting Diode
	A.PB	: Audio Playback	LIMIT AMP	: Limiter Amplifier
	APC	: Automatic Phase Control	LM, LDM	: Loading Motor
	ASS'Y	: Assembly	LP	: Long Play
	AT	: All Time	L.P.F	: Low Pass Filter
	AUTO	: Automatic	LUMI.	: Luminance
	A/V	: Audio/Video	M M	: Motor
B	BGP	: Burst Gate Pulse	MAX	: Maximum
	BOT	: Beginning of Tape	MINI	: Minimum
	BPF	: Bandpass Filter	MIX	: Mixer, mixing
	BRAKE SOL	: Brake Solenoid	MM	: Monostable Multivibrator
	BUFF	: Buffer	MOD	: Modulator, Modulation
	B/W	: Black and White	MPX	: Multiplexer, Multiplex
C	C	: Capacitance, Collector	MS SW	: Mecha State Switch
	CASE	: Cassette	N NC	: Non Connection
	CAP	: Capstan	NR	: Noise Reduction
	CARR	: Carrier	O OSC	: Oscillator
	CH	: Channel	OPE	: Operation
	CLK	: Clock	P PB	: Playback
	CLOCK (SY-SE)	: Clock (Syscon to Servo)	PB CTL	: Playback Control
	COMB	: Combination, Comb Filter	PB-C	: Playback-Chrominance
	CONV	: Converter	PB-Y	: Playback-Luminance
	CPM	: Capstan Motor	PCB	: Printed Circuit Board
	CTL	: Control	P. CON	: Power Control
	CYL	: Cylinder	PD	: Phase Detector
	CYL-M	: Cylinder-Motor	PG	: Pulse Generator
	CYL SENS	: Cylinder-Sensor	P-P	: Peak-to Peak
D	DATA (SY-CE)	: Data (Syscon to Servo)	R R	: Right
	dB	: Decibel	REC	: Recording
	DC	: Direct Current	REC-C	: Recording-Chrominance
	DD Unit	: Direct Drive Motor Unit	REC-Y	: Recording-Luminance
	DEMOD	: Demodulator	REEL BRK	: Reel Brake
	DET	: Detector	REEL S	: Reel Sensor
	DEV	: Deviation	REF	: Reference
E	E	: Emitter	REG	: Regulated, Regulator
	EF	: Emitter Follower	REW	: Rewind
	EMPH	: Emphasis	REV, RVS	: Reverse
	ENC	: Encoder	RF	: Radio Frequency
	ENV	: Envelope	RMC	: Remote Control
	EOT	: End of Tape	RY	: Relay
	EQ	: Equalizer	S S. CLK	: Serial Clock
	EXT	: External	S. COM	: Sensor Common
F	F	: Fuse	S. DATA	: Serial Data
	FBC	: Feed Back Clamp	SEG	: Segment
	FE	: Full Erase	SEL	: Select, Selector
	FF	: Fast Forward, Flipflop	SENS	: Sensor
	FG	: Frequency Generator	SER	: Search Mode
	FL SW	: Front Loading Switch	SI	: Serial Input
	FM	: Frequency Modulation	SIF	: Sound Intermediate Frequency
	FSC	: Frequency Sub Carrier	SO	: Serial Output
	FWD	: Forward	SOL	: Solenoid
G	GEN	: Generator	SP	: Standard Play
	GND	: Ground	STB	: Serial Strobe
H	H.P.F	: High Pass Filter	SW	: Switch

KEY TO ABBREVIATIONS

S	SYNC	:	Synchronization
	SYNC SEP	:	Sync Separator, Separation
T	TR	:	Transistor
	TRAC	:	Tracking
	TRICK PB	:	Trick Playback
	TP	:	Test Point
U	UNREG	:	Unregulated
V	V	:	Volt
	VCO	:	Voltage Controlled Oscillator
	VIF	:	Video Intermediate Frequency
	VP	:	Vertical Pulse, Voltage Display
	V.PB	:	Video Playback
	VR	:	Variable Resistor
	V.REC	:	Video Recording
	VSF	:	Visual Search Fast Forward
	VSR	:	Visual Search Rewind
	VSS	:	Voltage Super Source
	V-SYNC	:	Vertical-Synchronization
	VT	:	Voltage Tuning
X	X'TAL	:	Crystal
Y	Y/C	:	Luminance/Chrominance

SERVICE MODE LIST

This unit provided with the following SERVICE MODES so you can repair, examine and adjust easily.
 To enter to the SERVICE MODE function, press and hold both buttons simultaneously on the main unit or on the main unit and on the remote control for more than a standard time in the appropriate condition. (See below chart.)
 In case of the main unit and remote control, press the remote control buttons first, then press the main unit buttons.

Set Condition	Set Key	Set Key	Standard Time	Operations
VCR mode	CH UP	FF	2 sec.	PLAY/REC total hours are displayed on the TV Monitor. Refer to the "PREVENTIVE CHECKS AND SERVICE INTERVALS" (CONFIRMATION OF HOURS USED). Can be checked of the INITIAL DATA of MEMORY IC. Refer to the "WHEN REPLACING EEPROM (MEMORY) IC".
Power On	CH UP	PLAY	2 sec.	Initialization of the factory on VCR. NOTE: Do not use this for the normal servicing. If you set a factory initialization, the memories are reset such as the clock setting, the channel setting, and PLAY/REC total hours.
VCR mode (Playback)	CH UP	CH DOWN	2 sec.	Adjusting of the Tracking to the center position. NOTE: Also can be adjusted by pressing the ATR button for more than 2 seconds during PLAY.
VCR mode	CH UP	REC	2 sec.	The BOT, EOT, and the Reel Sensor do not work and the VCR deck can be operated without a cassette tape. Refer to the "PREPARATION FOR SERVICING"
VCR mode (Playback)	VCR/DVD	REC	2 sec.	Adjust the PG SHIFTER automatically. Refer to the "ELECTRICAL ADJUSTMENT".
Power Off	CH DOWN	POWER	2 sec.	VCR operation mode at no connection of DVD. Refer to the "PREPARATION FOR SERVICING" NOTE: Although the DVD is connected, the DVD mode cannot be selected.

Set Condition	Set Key	Remocon Key	Standard Time	Operations
DVD mode (STOP)	STOP	0	2 sec.	Tray cannot be opened. Refer to the "TRAY LOCK". NOTE: No indications on the screen when the Tray Lock is setting. The function will only work without the setting of DVD disc at DVD mode.
DVD mode (No disc)	STOP	6	2 sec.	Initialization of the factory on DVD. NOTE: Do not use this for the normal servicing. This function will only work without the setting of DVD disc at DVD mode. While pressing the Remocon Key for more than 2 seconds, press the Set Key simultaneously.
DVD mode (No disc)	STOP	7	2 sec.	Releasing of PARENTAL LOCK. Refer to the "PARENTAL CONTROL - RATING LEVEL". NOTE: The function will only work without the setting of DVD disc at DVD mode.

PREVENTIVE CHECKS AND SERVICE INTERVALS

The following standard table depends on environmental conditions and usage.

Parts replacing time does not mean the life span for individual parts.

Also, long term storage or misuse may cause transformation and aging of rubber parts.

The following list means standard hours, so the checking hours depends on the conditions.

Time Parts Name	500 hours	1,000 hours	1,500 hours	2,000 hours	2,500 hours	Notes
Audio Control Head	■	■	■	●	●	Clean those parts in contact with the tape.
Full Erase Head (Recorder only)	■	■	■	●	●	
Capstan Belt		●	●	●	●	Clean the rubber, and parts which the rubber touches.
Pinch Roller	■	●	●	●	●	
Capstan DD Unit		●	●	●	●	
Loading Motor					●	
Tension Band		●	●	●	●	
T Brake Band		●	●	●	●	
Clutch Ass'y		●	●	●	●	
Idler Arm Ass'y		●	●	●	●	
Capstan Shaft	■	■	■	■	■	Replace when rolling becomes abnormal.
Tape Running Guide Post	■	■	■	■	■	
Cylinder Unit	■	●	●	●	●	Clean the Head

■ : Clean

● : Check it and if necessary, replace it.

CONFIRMATION OF HOURS USED

PLAY/REC total hours can be checked on the screen.

Total hours are displayed in 16 system of notation.

NOTE: If you set a factory initialization, the total hours is reset to "0".

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the VCR mode.
3. Press both CH UP button on the set and the FF button on the set for more than 2 seconds.
The Fig. 1 screen will appear on TV Monitor.
4. After the confirmation of using hours, turn off the power.




Fig. 1

PREVENTIVE CHECKS AND SERVICE INTERVALS


CLEANING

NOTE

After cleaning the heads with isopropyl alcohol, do not run a tape until the heads dry completely. If the heads are not completely dry and alcohol gets on the tape, damage may occur.

1. AUDIO CONTROL HEAD

Clean the Audio Control Head with the cotton stick soaked by alcohol. Clean the full erase head in the same manner. **(Refer to the figure below.)**



2. TAPE RUNNING SYSTEM


When cleaning the tape transport system, use the gauze moistened with isopropyl alcohol.

3. CYLINDER

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol. Hold it to the cylinder head softly. Turn the cylinder head counterclockwise to clean it (in the direction of the arrow). **(Refer to the figure below.)**

NOTE

Do not exert force against the cylinder head. Do not move the chamois upward or downward on the head. Use the chamois one by one.



WHEN REPLACING EEPROM (MEMORY) IC

If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to TABLE 1.

NOTE: No need setting for after INIT 59.

INIT	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+A	+B	+C	+D	+E	+F
00	E7	41	78	04	12	CE	36	AF	98	95	8A	1B	2A	09	29	13
10	44	84	28	34	34	4A	A7	51	9F	3A	00	0D	BF	10	00	00
20	64	42	30	60	56	65	5F	00	9F	18	FA	5F	00	00	00	00
30	00	00	00	00	00	00	00	00	00	00	5F	00	9F	18	FA	4F
40	00	00	00	AF	00	AF	FF	0F	00	00	21	01	00	2D	0C	0E
50	7A	00	00	70	05	00	00	00	00	00	---	---	---	---	---	---

Table 1

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the VCR mode.
3. Press both CH UP button on the set and the FF button on the set for more than 2 seconds.
ADDRESS and DATA will appear on TV Monitor as Fig 1.














Fig. 1

4. ADDRESS is now selected and should "blink". Using the Tracking + or - button on the remote, step through the ADDRESS until required ADDRESS to be changed is reached.
5. Press ENTER to select DATA. When DATA is selected, it will "blink".
6. Again, step through the DATA using Tracking + or - button until required DATA value has been selected.
7. Pressing ENTER will take you back to ADDRESS for further selection if necessary.
8. Repeat steps 4 to 7 until all data has been checked.
9. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input.

After the data input, set to the initializing of shipping.

10. Turn on the POWER, and set to the VCR mode.
11. Press both CH UP button on the set and the PLAY button on the set for more than 2 seconds.
12. After the finishing of the initializing of shipping, the unit will turn off automatically.
The unit will now have the correct DATA for the new MEMORY IC.

SERVICING FIXTURES AND TOOLS

(For 2 head 1 speed model, 4 head model) VHS Alignment Tape JG001E (VP ₁ S-LI6 ³) JG001F (VP ₁ S-CO1 ³) JG001R (VP ₁ S-LI6 ³ H) JG001U (VP ₁ S-X6 ³) 	(For 2 head 2 speed model) VHS Alignment Tape JG001C (VP ₂ S-LI6 ³) JG001D (VP ₂ S-CO1 ³) JG001V (VP ₂ S-X6 ³) 	JG002B Adapter JG002E Dial Torque Gauge (10~90gf•cm) JG002F (60~600gf•cm) 	JG005 Post Adjustment Screwdriver Part No. SV-TG0-030-000 (small) 
JG153 X Value Adjustment Screwdriver 	JG022 Master Plane 	JG024A Reel Disk Height Adjustment Jig 	JG100A Torque Tape (VHT-063) 
JG154 Cable 	JG185 Tentelometer 		

Ref. No.	Part No.	Parts Name	Remarks
JG001E	APJG001E00	VHS Alignment Tape	Monoscope, 6KHz (For 2 head 1 speed model, 4 head model)
JG001F	APJG001F00	VHS Alignment Tape	Color Bar, 1KHz (For 2 head 1 speed model, 4 head model)
JG001R	APJG001R00	VHS Alignment Tape	Hi-Fi Audio (For Hi-Fi model)
JG001U	APJG001U00	VHS Alignment Tape	X Value Adjustment (For 2 head 1 speed model, 4 head model)
JG001C	APJG001C00	VHS Alignment Tape	Monoscope, 6KHz (For 2 head 2 speed model)
JG001D	APJG001D00	VHS Alignment Tape	Color Bar, 1KHz (For 2 head 2 speed model)
JG001V	APJG001V00	VHS Alignment Tape	X Value Adjustment (For 2 head 2 speed model)
JG002B	APJG002B00	Adapter	VSR Torque, Brake Torque (S Reel/T Reel Ass'y)
JG002E	APJG002E00	Dial Torque Gauge (10~90gf•cm)	Brake Torque (T Reel Ass'y)
JG002F	APJG002F00	Dial Torque Gauge (60~600gf•cm)	VSR Torque, Brake Torque (S Reel)
JG005	APJG005000	Post Adjustment Screwdriver	Guide Roller Adjustment
JG153	APJG153000	X Value Adjustment Screwdriver	X Value Adjustment
JG022	APJG022000	Master Plane	Reel Disk Height Adjustment
JG024A	APJG024A00	Reel Disk Height Adjustment Jig	Reel Disk Height Adjustment
JG100A	APJG100A00	Torque Tape (VHT-063)	Playback Torque, Back Tension Torque During Playback
JG154	APJG154000	Cable	Used to connect the test point of SERVICE and GROUND
JG185	APJG185000	Tentelometer	Confirmation of Tape Tension on Playback

PREPARATION FOR SERVICING

- While pressing the CH DOWN button on the set for more than 2 seconds, press the POWER button on the set simultaneously at the Power OFF. Although the DVD is connected, the DVD mode cannot be selected.
- Press both CH UP button on the set and the REC button on the set for more than 2 seconds.
(The BOT, EOT, and the Reel Sensor do not work and the VCR deck can be operated without a cassette tape.)
- In case of using a cassette tape, press the EJECT button to insert or eject a cassette tape.
Turn on the power and re-check the cable before checking the trouble points.

When you servicing with connection of DVD, perform the operations above step 2 to step 3.

MECHANICAL ADJUSTMENTS



1. CONFIRMATION AND ADJUSTMENT

Read the following NOTES before starting work.

- Place an object which weighs between 450g~500g on the Cassette Tape to keep it steady when you want to make the tape run without the Cassette Holder. (Do not place an object which weighs over 500g.)



1-1: CONFIRMATION AND ADJUSTMENT OF REEL DISK HEIGHT

- Turn on the power and set to the STOP mode.
- Set the master plane (**JG022**) and reel disk height adjustment jig (**JG024A**) on the mechanism framework, taking care not to scratch the drum, as shown in **Fig. 1-1-A**.
- While turning the reel and confirm the following points. Check if the surface "A" of reel disk is lower than the surface "B" of reel disk height adjustment jig (**JG024A**) and is higher than the surface "C". If it is not passed, place the height adjustment washers and adjust to $10(+2, -0)$ mm.
- Adjust the other reel in the same way.



1-2: CONFIRMATION AND ADJUSTMENT OF TENSION POST POSITION

- Set to the PLAY mode.
- Adjust the adjusting section for the Tension Arm position so that the Tension Arm top is within the standard line of Main Chassis.
- While turning the S Reel clockwise, confirm that the edge of the Tension Arm is located in the position described above.




1-3: CONFIRMATION OF PLAYBACK TORQUE AND BACK TENSION TORQUE DURING PLAYBACK

- Load a video tape (E-180) recorded in standard speed mode. Set the unit to the PLAY mode.
- Install the tentelometer (**JG185**) as shown in **Fig. 1-3**. Confirm that the meter indicates 20 ± 2 gf in the beginning of playback.

• USING A CASSETTE TYPE TORQUE TAPE (**JG100A**)

- After confirmation and adjustment of Tension Post position (Refer to item 1-2), load the cassette type torque tape (**JG100A**) and set to the PLAY mode.
- Confirm that the right meter of the torque tape indicates $50 \sim 90$ gf•cm during playback in SP mode.
- Confirm that the left meter of the torque tape indicates $25 \sim 40$ gf•cm during playback in SP mode.



MECHANICAL ADJUSTMENTS

1-4: CONFIRMATION OF VSR TORQUE

1. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Set to the Picture Search (Rewind) mode. (Refer to Fig.1-4-B)
2. Then, confirm that it indicates 120~180gf•cm.

NOTE

Install the Torque Gauge on the reel disk firmly. Press the REW button to turn the reel disk.

1-5: CONFIRMATION OF REEL BRAKE TORQUE

(S Reel Brake) (Refer to Fig. 1-4-B)

1. Once set to the Fast Forward mode then set to the Stop mode. While, unplug the AC cord when the Pinch Roller Block is on the position of Fig. 1-4-A.
2. Move the Idler Ass'y from the S Reel.
3. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Turn the Torque Gauge (JG002F) clockwise.
4. Then, confirm that it indicates 60~100gf•cm.

(T Reel Brake) (Refer to Fig. 1-4-B)

1. Once set to the Fast Forward mode then set to the Stop mode. While, unplug the AC cord when the Pinch Roller Block is on the position of Fig. 1-4-A.
2. Move the Idler Ass'y from the T Reel.
3. Install the Torque Gauge (JG002E) and Adapter (JG002B) on the T reel. Turn the Torque Gauge (JG002E) counterclockwise.
4. Then, confirm that it indicates 30~50gf•cm.




Fig. 1-4-A




Fig. 1-4-B

NOTE

If the torque is out of the range, replace the following parts.

Check item	Replacement Part
1-4	Idler Ass'y/Clutch Ass'y
1-5	S Reel side: S Reel/Tension Band/Tension Connect/Tension Arm Ass'y T Reel side: T Reel/T Brake Band//T Brake Spring/T Brake Arm

2. CONFIRMATION AND ADJUSTMENT OF TAPE RUNNING MECHANISM

Tape Running Mechanism is adjusted precisely at the factory. Adjustment is not necessary as usual. When you replace the parts of the tape running mechanism because of long term usage or failure, the confirmation and adjustment are necessary.

2-1: GUIDE ROLLER

1. Playback the VHS Alignment Tape (JG001C or JG001E). (Refer to SERVICING FIXTURE AND TOOLS)
2. Connect CH-1 of the oscilloscope to TP103 (Envelope) and CH-2 to TP102 (SW Pulse).
3. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
4. Trigger with SW Pulse and observe the envelope. (Refer to Fig. 2-1-A)
5. When observing the envelope, adjust the Adjusting Driver (JG005) slightly until the envelope will be flat. Even if you press the Tracking Button, adjust so that flatness is not moved so much.
6. Adjust so that the A : B ratio is better than 3 : 2 as shown in Fig. 2-1-B, even if you press the Tracking Button to move the envelope (The envelope waveform will begin to decrease when you press the Tracking Button).
7. Adjust the PG shifter during playback. (Refer to the ELECTRICAL ADJUSTMENTS)

NOTE

After adjustment, confirm and adjust A/C head. (Refer to item 2-2)




Fig. 2-1-A







Fig. 2-1-B

MECHANICAL ADJUSTMENTS

2-2: CONFIRMATION AND ADJUSTMENT OF AUDIO/CONTROL HEAD


When the Tape Running Mechanism does not work well, adjust the following items.

1. Playback the VHS Alignment Tape (JG001C or JG001E). (Refer to **SERVICING FIXTURE AND TOOLS**)
2. Confirm that the reflected picture of stamp mark is appeared on the tape prior to P4 Post as shown in **Fig. 2-2-A**.
 - a) When the reflected picture is distorted, turn the screw ① clockwise until the distortion is disappeared.
 - b) When the reflected picture is not distorted, turn the screw ① counterclockwise until little distortion is appeared, then adjust the a).
3. Turn the screw ② to set the audio level to maximum.
4. Confirm that the bottom of the Audio/Control Head and the bottom of the tape is shown in **Fig. 2-2-C**.
 - c) When the height is not correct, turn the screw ③ to adjust the height. Then, adjust the 1~3 again.



2-3: TAPE RUNNING ADJUSTMENT (X VALUE ADJUSTMENT)

1. Confirm and adjust the height of the Reel Disk. (Refer to item 1-1)
2. Confirm and adjust the position of the Tension Post. (Refer to item 1-2)
3. Adjust the Guide Roller. (Refer to item 2-1)
4. Confirm and adjust the Audio/Control Head. (Refer to item 2-2)
5. Connect CH-1 of the oscilloscope to TP102, CH-2 to TP103 and CH-3 to **HOT side of Audio Out Jack**.
6. Playback the VHS Alignment Tape (JG001U or JG001V). (Refer to **SERVICING FIXTURE AND TOOLS**)
7. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
8. Set the X Value adjustment driver (JG153) to the ④ of **Fig. 2-2-B**. Adjust X value so that the envelope waveform output becomes maximum. Check if the relation between Audio and Envelope waveform becomes (1) or (2) of **Fig. 2-3**.




2-4: CONFIRM HI-FI AUDIO (Hi-Fi model only)

1. Connect CH-1 of the oscilloscope to TP102 and CH-2 to the **Hi-Fi Audio Out Jack**.
2. Playback the VHS Alignment Tape (JG001R). (Refer to **SERVICING FIXTURE AND TOOLS**)
3. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
4. Press the Tracking Up button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
5. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
6. Press the Tracking Down button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
7. If the difference are more than 3 steps, set the X Value adjustment driver (JG153) to ④ of **Fig. 2-2-B**. Change the X Value and adjust it so that the value becomes within 2 steps.

MECHANICAL ADJUSTMENTS

3. MECHANISM ADJUSTMENT PARTS LOCATION GUIDE



ELECTRICAL ADJUSTMENTS

Read and perform this adjustment when repairing the circuits or replacing electrical parts or PCB assemblies.

1. BASIC ADJUSTMENT

CAUTION

- When you exchange IC and Transistor for a heat sink, apply the silicon grease (**YG6260M**) on the contact section of the heat sink. Before applying new silicon grease, remove all the old silicon grease. (Old grease may cause damages to the IC and Transistor.)

1-1: PG SHIFTER



CONDITIONS

MODE-PLAYBACK

Input Signal-Alignment Tape (**JG001E**)


INSTRUCTIONS

- Connect CH-1 on the oscilloscope to **TP102** and CH-2 to **J8001**.
- Playback the alignment tape. (**JG001E**)
- Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
- Press both CH UP button on the set and the STOP button on the set for more than 2 seconds.



ELECTRICAL ADJUSTMENTS

2. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE (WIRING CONNECTION)



Zentralwerkstatt und
Ersatzteildepot
für ORION-Produkte



Postfach 10 10 26
63264 Dreieich
Max-Planck-Str. 20
63303 Dreieich

Ersatzteil-Bestellung

Tel.: (06103) 39 99-95 Fax.: (06103) 39 99-79

SERVICE MANUAL



Nachdruck bzw. Kopieren dieser Unterlagen ist grundsätzlich verboten!

Teil 2

ORION

VDR-4002

DVD-RW RECORDER & VHS VIDEO CASSETTE RECORDER




ORIGINAL CHASSIS CODE A

Best. Nr. SM4002-2


Design and specifications are subject to change without notice.

MPEGBLOCKDIAGRAM



- | | | |
|---|---------------|-----------|
| A | MP.P.CON+1.8V | REGULATOR |
| B | MP.P.CON+2.5V | |
| C | MP.P.CON+3.3V | |
| D | MP.P.CON+5V | |
| E | MP.P.CON+5V | |
| | | |
| F | P.CON+12V | POWER |
| G | P.CON+5V | |


Y/C/AUDIO/HEAD AMP BLOCK DIAGRAM




SYSCON/TIMER/SERVO
IC3001 OEC0145A




REGULATOR BLOCK DIAGRAM




OPERATION/DISPLAY BLOCK DIAGRAM




AV IN/OUT/TUNER/HI-FI BLOCK DIAGRAM




21PIN IN/OUT BLOCK DIAGRAM




POWER BLOCK DIAGRAM



DVD/HD MPEG (TOP SIDE)




DVD/HD MPEG (BOTTOM SIDE)




PRINTED CIRCUIT BOARDS


**POWER
SOLDER SIDE**




OPERATION SOLDER SIDE




PRINTED CIRCUIT BOARDS
VCR (INSERTED PARTS)
SOLDER SIDE



PRINTED CIRCUIT BOARDS
VCR (CHIP MOUNTED PARTS)
SOLDER SIDE



AV ENCODER SCHEMATIC DIAGRAM




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE:THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCBB10
VMD334

MPEG SCHEMATIC DIAGRAM





NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCB810
VM0734

MEMORY SCHEMATIC DIAGRAM (DVD/HD MPEG PCB)




NOTES: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCB81Q
VMD334

(DVD/HD MPEG PCB)



NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCBB 10
VMD334

(DVD/HD MPEG PCB)




(DVD/HD MPEG PCB)



PCB810
VMD334


(DVD/HD MPEG PCB)



NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


PCBB10
VMD334

AVD/HD MPEG PCB)



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE. NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


Y/C/AUDIO/HEAD AMP SECAM SCHEMATIC DIAGRAM (VCR PCB)




NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: DIGITAL TRANSISTOR




SYSCON/SERVO/TIMER SCHEMATIC DIAGRAM (VCR PCB)




ATTENTION: LES PIÈCES RÉPARÉES PAR UN Δ ÉTANT DANGEREUSES AU POINT DE VUE SÉCURITÉ, N'UTILISEZ QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

CAUTION: SINCE THESE PARTS MARKED BY Δ ARE DANGEROUS AS POINTS OF VIEW SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.



AV IN/OUT SCHEMATIC DIAGRAM (VCR PCB)



The diagram shows a square circuit symbol on the left, which is transformed via an arrow into a detailed transistor symbol on the right. The transistor symbol includes a base, emitter, and collector, with a resistor connected to the base.


NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

ATTENTION LES PIECES REPARÉES PAR UN
DANGEREUSES AN POINT DE VUE SECURITE
UTILISER QUE CELLS DECRITES
DANS LA NOMENCLATURE DES PIECES

CAUTION SINCE THESE PARTS MARKED **CR** ARE
CRITICAL FOR SAFETY, USE ONES
DESCRIBED IN PARTS LIST ONLY

NOTETHIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE


21PIN IN/OUT SCHEMATIC DIAGRAM (VCR PCB)



NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE

CAUTION: DIGITAL TRANSISTOR



PCB010
VMD320

(VCR PCB)




ATTENTION LES PIÈCES RÉPARÉES PAR MITTANT **CAUTION** SINCE THESE PARTS MARKED BY ARE
DANGEREUSES AU POINT DE VUE SÉCURITÉ CRITICAL FOR SAFETY, USE ONES
UTILISER QUE CELLES DÉCRITES DESCRIBED IN PARTS LIST ONLY
DANS LA NOMÉNCLATURE DES PIÈCES

CAUTION: DIGITAL TRANSISTOR



DISPLAY SCHEMATIC DIAGRAM

(VCR PCB)




NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

PCB010
VMD329


Hi-Fi SCHEMATIC DIAGRAM




NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTES: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE

CAUTION: DIGITAL TRANSISTOR




CAUTION: DIGITAL TRANSISTOR



PCB010
VMD329

POWER SCHEMATIC DIAGRAM


(POWER PCB)



CAUTION: THESE PARTS MARKED ARE CRITICAL FOR SAFETY. USE ONES DESCRIBED IN PARTS LIST ONLY.
 ATTENTION: CES PIÉCES MARQUÉES SONT DANGEREUSES AU POINT DE VUE DE LA SÉCURITÉ. UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÉCES.
 THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.
 THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

OPERATION/LED SCHEMATIC DIAGRAM


(OPERATION PCB)



NOTE: THE DC VOLTAGE EACH PART WAS
MEASURED WITH THE DIGITAL TESTER
DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE

INTERCONNECTION DIAGRAM






CAUTION THESE PARTS MARKED ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY

ATTENTION LES PIÈCES REPAREES PAR UN TECHNICIEN DANGEREUSES AN POINT DE VUE SECURITE NUTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES RECHES












NOTES: THIS INTERCONNECTION DIAGRAM IS THE LATEST NAME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE

WAVEFORMS

AV ENCODER






MPEG






NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

WAVEFORMS


MEMORY




FPGA







VIDEO DECODER



AUDIO ADC















AUDIO DAC






NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

WAVEFORMS

SYSCON/SERVO/TIMER




Y/C/AUDIO/HEAD AMP




NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

MECHANICAL EXPLODED VIEW




CHASSIS EXPLODED VIEW (TOP VIEW)



CLASS	PART NO.	PART NAME	MARK
GREASE	Y315061000	G-555G	AA
	Y315071000	MG-33	AB
	Y31D011000	FG-84M	AC
	Y315041000	FL-721	AD
	Y315141000	G-313Y	AE

NOTE: Applying positions AA, AB, AC, AD and AE for the grease are displayed for this section. Check if the correct grease is applied for each position.

CHASSIS EXPLODED VIEW (BOTTOM VIEW)



CLASS	PART NO.	PART NAME	MARK
GREASE	Y315061000	G-555G	AA
	Y315071000	MG-33	AB
	Y31D011000	FG-84M	AC
	Y315041000	FL-721	AD
	Y315141000	G-313Y	AE

NOTE: Applying positions AA, AB, AC, AD and AE for the grease are displayed for this section. Check if the correct grease is applied for each position.

MECHANICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	
101	7A7010012B	FRONT,CABI ASS'Y	
101A	701WPJ1272	CABINET,FRONT	
101B	711WPD0654	PLATE,DISPLAY	
101C	712WPJ0861	FLAP,VCR	
101D	712WPQ0002	FLAP,DVD	
101E	713WPA0303	GLASS,LED-DVD	
101F	713WPA0304	GLASS,LED-VCR	
101G	7232020756	BADGE,BRAND	
101H	738WPA0083	STOPPER,BUTTON	
101I	738WPB0024	BUTTON,FRAME-DVD	
101J	738WPB0025	BUTTON,FRAME-VCR	
101K	743WKA0042	SPRING,FLAP	
101L	743WKA0050	SPRING,FLAP-DVD	
101M	800WFA0045	CUSHION,LEG	
101N	753WUA0067	SPRING,EARTH DISPLAY	
102	7G7610003B	BOTTOM,CABI ASS'Y	
102A	702WSA0209	PLATE,BOTTOM	
102B	761WSA0154	ANGLE,CENTER	
103	761WSA0104	SHIELD,21PIN	
104	753WUA0062	SPRING,EARTH-TOP	
105	8965TS2020	CUSHION	20x15x12
106	701WPA0686	HOLDER,DECK	
107	701WPA0751	HOLDER,DECK	
108	752WSA0230	SHIELD,CASE H/AMP	
109	753WUAA006	SPRING,EARTH H/AMP	
110	85OP700038	HOLDER,END SENSOR	
111	7222022662	SHEET,RATING	
112	899EFBA002	WIRING-CLIP	
113	752WSA0275	COVER,AC HEAD	
114	752WSA0290	SHIELD,COMPO	
115	752WSA0391	SHIELD,MPEG	
116	752WUA0008	SHIELD,JACK	
117	761WSA0150	ANGLE,DVD(L)	
118	761WSA0151	ANGLE,DVD(R)	
119	701WPA0781	HOLDER,TOP	
120	702WSB0092	CABINET,TOP	
121	800WFA0055	CUSHION	20x5xT1
122	8965TS1017	CUSHION	17.5x20x14
123	713WPA0308	HOLDER,DVD	
201	8109130B94	SCREW,TAP TITE(B) R PAN	3x29
202	8109230704	SCREW,TAP TITE(B) R BIND	3x7
203	8109130A04	SCREW,TAP TITE(B) WH7	3x10
204	8109230804	SCREW,TAP TITE(B) BIND	3x8
205	8109K30601	SCREW,TAP TITE(B) BIND	3x6
206	8107230404	SCREW,TAP TITE(S) BIND	3x4
207	8110E26804	SCREW,TAP TITE(P) WH10	M2.6x8
208	8110226804	SCREW,TAP TITE(P) BIND	2.6x8
209	8102230604	SCREW,BIND	M3x6
---	791WHA0108	GIFT,SHEET	
---	792WHA0516	PACKAGE,FRONT	
---	792WHA0519	PACKAGE,BACK	
---	793WCD1548	GIFT BOX	
---	795WCA0662	PAD,DVD/VR	155x250
---	A2D501T975	INSTRUCTION BOOK KIT	
---	J2D50101A	INSTRUCTION BOOK	
---	J2A50429A	INFORMATION SHEET	
---	JB5U0200	POLYBAG,INSTRUCTION	

CHASSIS REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
300	A2D501A420A	DECK ASSY A2D501A420A	501	8107226804	SCREW,TAP TITE(S) BIND 2.6x8
301	85OA400240	PINCH ROLLER BLOCK (VA)	502	83ETW30000	E-RING 3.0
302	85OA500026	AHC ASS'Y	503	8107226404	SCREW,TAP TITE(S) BIND 2.6x4
303	85OP200290	BELT,CAPSTAN (S)	504	8102120604	SCREW,PAN M2x6
304	85OP600581	WORM	505	8109126604	SCREW,TAP TITE(B) PAN 2.6x6
305	85OP500083	BASE,AC HEAD	506	810A130404	SCREW/WASHER(A) M3x4
306	85OP800324	SPRING,AC HEAD	507	810A126504	SCREW/WASHER(A) M2.6x5
307	85OA000459	MAIN CHASSIS ASS'Y	508	82Q264713N	POLYSLIDER WASHER 2.6x4.7xT0.13
308	85OA200089	CLUTCH ASS'Y	509	82P184505N	POLYSLIDER WASHER(CUT) 1.8x4.5xT0.5
309	85OA200090	ARM IDLER ASS'Y	510	8107226604	SCREW,TAP TITE(S) BIND 2.6x6
310	85OA300065	LOADING ARM S UNIT	CD1501	122H071603	CORD JUMPER SMCD-7X151
311	85OA300066	LOADING ARM T UNIT	CD1502	122Y021902	CORD JUMPER 2Y021902
312	85OA400223	INCLINED BASE T UNIT 3S	H5001	1523Q91003	HEAD (AUDIO CONTROL) VTR-1X2RPE22-756
313	85OA400232	P5 ARM ASS'Y 2	H5002	1543Q02014	HEAD (FULL ERASE) VTR-1X2ERS11-154
314	85OA400235	TENSION ARM ASS'Y 2	△ M101	1596S98001	MOTOR (LOADING) MDB2B66
315	85OA400231	INCLINED BASE S UNIT	△ M2001	1510S98043	CAPSTAN DD UNIT F2QVB58
316	85OP800367	SPRING,LOCKER	△ M2003	1589S11020	MICRO MOTOR I2OAL34
317	85OP900736	CASS,HOLDER	△ UN4001	A2D501A500	CYLINDER UNIT ASS'Y A2D501A500
318	85OP900748	CASS,SIDE L			
319	85OP900749	CASS,SIDE R			
320	85OP900739	LOCKER,R			
321	85OA900228	LINK UNIT			
322	85OP000496	POST,CASS GUIDE			
323	85OP200316	REEL,S (S)			
324	85OP200317	REEL,T (S)			
325	85OP200308	GEAR,IDLER			
326	85OP200311	GEAR,CLUTCH			
327	85OP200312	GEAR,COUPLING			
328	85OP200313	LEVER,CLUTCH			
329	85OP300194	GEAR,MAIN LOADING			
330	85OP400490	LEVER,TENSION			
331	85OP400492	HOLDER,TENSION			
332	85OP400520	CAP.P4			
333	85OP400542	BAND,TENSION			
334	85OP400533	CONNECT,TENSION			
335	85OP600573	ARM,BRAKE T			
336	85OP600584	BAND,BRAKE T			
337	85OP600577	CAM,PINCH ROLLER			
338	85OP600578	CAM,MAIN			
339	85OP600579	ROD,MAIN			
340	85OP600582	GEAR,JOINT			
341	85OP800322	SPRING,TENSION			
342	85OP800360	SPRING,BRAKE T			
343	85OP800355	SPRING,COUPLING			
344	85OP800356	SPRING,RING			
345	85OP900750	LEVER,LINK 2			
346	85OP900744	LEVER,FLAP			
347	85OP900745	CASS,OPENER			
348	85OP700035	REFLECTOR,LED			
349	85OP900746	BRACKET,TOP 3V			
350	85OP400549	HOLDER,CAPSTAN			

ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
RESISTORS			DIODES		
△ R502	R3X181R82J	R,METAL OXIDE 0.82 OHM 1W	D8011	D1VT001330	DIODE,SILICON 1SS133T-77
△ R504	R3X181561J	R,METAL OXIDE 560 OHM 1W	D8012	D1VT001330	DIODE,SILICON 1SS133T-77
R505	R012U2474J	RC 470K OHM 1/2W	D8301	D1VTB721Q0	DIODE,SCHOTTKY RB721Q-40 T-77
△ R512	R3X28A104J	R,METAL OXIDE 100K OHM 2W	D8303	D1VTB721Q0	DIODE,SCHOTTKY RB721Q-40 T-77
△ R516	R63581R22J	R,FUSE 0.22 OHM 1W	D8307	D1VTB721Q0	DIODE,SCHOTTKY RB721Q-40 T-77
△ R531	R65584220J	R,FUSE 22 OHM 1/4W	D8310	D1VTB721Q0	DIODE,SCHOTTKY RB721Q-40 T-77
△ R532	R3X181121J	R,METAL OXIDE 120 OHM 1W	D8314	D1VTB721Q0	DIODE,SCHOTTKY RB721Q-40 T-77
△ R533	R655842R7J	R,FUSE 2.7 OHM 1/4W	ICS		
△ R538	R65584150J	R,FUSE 15 OHM 1/4W	IC101	I04F38225F	IC HA118225F
△ R539	R3X28A010J	R,METAL OXIDE 1 OHM 2W	IC301	I03S072100	IC LA7210
R1725	R65584101J	R,FUSE 100 OHM 1/4W	△ IC501	I0CJ9AILP0	IC TL431AILP
CAPACITORS			△ IC502	I1KA78R120	IC KIA278R12PI
C501	E62FF3102M	CE 1000 UF 25V	△ IC503	000220002W	IC PHOTO COUPLER PS2561AL1-1-V(W)
△ C502	P2122B104M	CMP 0.1 UF 275V ECQUL	△ IC651	IF4K063150	IC PT6315
△ C504	P2122B104M	CMP 0.1 UF 275V ECQUL	IC701	I03F7646SM	IC LA72646SM-MPB
C511	E62PFH181M	CE 180 UF 400V	IC702	I0QJ045800	IC NJM4580M(Te1)
C513	C0PLRR7H2K	CC 220 PF 2KV R	IC801	I19FF34170	IC MSP3417G-QG-B8
C515	C0J0B0514K	CC 0.01 UF 500V B	△ IC1701	I07F90WTP0	IC BA00BC0WT-V5
△ C516	CD39E0ML3M	CC 0.0033UF 250V	△ IC1702	I0CJ9AILP0	IC TL431AILP or
C518	E62F01222M	CE 2200 UF 10V	△ IC1703	I1KJ9A431A	IC KIA431A-AT
C519	E62F01222M	CE 2200 UF 10V	△ IC1704	I07F90WTP0	IC BA00BC0WT-V5
C525	C0PLRR7H2K	CC 220 PF 2KV R	△ IC1705	I1KA98R12A	IC KIA78R12API
C542	C0JBB0712K	CC 100 PF 2KV B	△ IC1706	I07F90WTP0	IC KIA78R12API
C543	C0JBB0712K	CC 100 PF 2KV B	△ IC3001	I54F50145A	IC BA00BC0WT-V5
DIODES			IC3003	IE2F031020	IC OEC0145A
D101	D1VT001330	DIODE,SILICON 1SS133T-77	IC3099	A2D501T015	IC XC61CN3102SR
△ D502	D2WTRM11C0	DIODE,SILICON RM11C-EIC	IC4001	ICQM067500	IC INIT DATA ZR36750E
△ D503	D2WTRM11C0	DIODE,SILICON RM11C-EIC	IC4002	I57F04L160	IC BR24L16FJ-WE2
D504	D1VT001330	DIODE,SILICON 1SS133T-77	IC4003	I97F052290	IC BD5229G
△ D505	D2WTRM11C0	DIODE,SILICON RM11C-EIC	IC4004	ICLJ020CT7	IC HY57V561620CT-7
△ D506	D2WTRM11C0	DIODE,SILICON RM11C-EIC	IC4005	ICLJ020CT7	IC HY57V561620CT-7
△ D507	D28F31DQ09	DIODE,SCHOTTKY 31DQ09-FC	IC4006	I5IJ0640BS	IC LH28F640BFHE-PTTL80
△ D508	D23TGP15J0	DIODE,SILICON RGP15J-G23	IC4007	I52K010520	IC UPD61052GD-LML
D509	D2BXARS010	DIODE,SILICON SARS01-V1	IC4008	IF3J00HGT7	IC HY57V641620HGT-7
△ D510	D97U02201B	DIODE,ZENER MTZJ22B T-77	IC4009	IF3J00HGT7	IC HY57V641620HGT-7
△ D512	D2LKB340F0	DIODE,SCHOTTKY SB340FL-6737	IC4010	IFAK030640	IC EPM3064ATC44-7(36060)
D514	D1VT001330	DIODE,SILICON 1SS133T-77	IC7301	I17F02KEG0	IC PCM1742KEG/2K
△ D515	D27A85T400	DIODE,SCHOTTKY RB085T-40	IC8001	I03F0026A0	IC LA73026AV-TLM-E
D516	D1VT001330	DIODE,SILICON 1SS133T-77	IC8002	I0UF015010	IC MM1501XNRE
D517	D1VT001330	DIODE,SILICON 1SS133T-77	IC8003	I0UF015060	IC MM1506XNRE
△ D518	D1VT001330	DIODE,SILICON 1SS133T-77	IC8004	I0UF015060	IC MM1506XNRE
D519	D97U02701B	DIODE,ZENER MTZJ27B T-77	IC8005	I0UF015060	IC MM1506XNRE
D520	D1VT001330	DIODE,SILICON 1SS133T-77	IC8006	I0QF02534V	IC NJM2534V(Te2)
△ D521	D28TELS2N2	DIODE,RECTIFIER 10ELS2N-TA1B2	IC8007	I0QF02534V	IC NJM2534V(Te2)
△ D522	D28TELS2N2	DIODE,RECTIFIER 10ELS2N-TA1B2	IC8501	I5OK071150	IC SAA7115HL
△ D523	D97U03301B	DIODE,ZENER MTZJ33B T-77	IC8502	I17F017050	IC PLL1705DBQR
D524	D1VT001330	DIODE,SILICON 1SS133T-77	IC8504	IFJ087750	IC WM8775EDS/R
△ D525	D28T21DQ09	DIODE,SCHOTTKY 21DQ09N-TA2B1	TRANSISTORS		
D529	D1VT001330	DIODE,SILICON 1SS133T-77	Q101	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D530	D28TELS6N6	DIODE,RECTIFIER 10ELS6N-TA1B2	Q102	TCAT032034	TRANSISTOR,SILICON KTC3203_Y-AT
D531	D97U01001B	DIODE,ZENER MTZJ10B T-77	Q103	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
△ D532	D28TQS04N0	DIODE,SCHOTTKY 11EQS04N-TA1B2	Q104	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D533	D1VT001330	DIODE,SILICON 1SS133T-77	Q105	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D534	D97U02R41B	DIODE,ZENER MTZJ2.4B T-77	Q108	TAAA1504SY	TRANSISTOR,SILICON KTA1504S_Y_RTK
D535	D97U05R61B	DIODE,ZENER MTZJ5.6B T-77	Q301	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D536	D97U05R61B	DIODE,ZENER MTZJ5.6B T-77	Q302	TAAA1504SY	TRANSISTOR,SILICON KTA1504S_Y_RTK
D538	D1VT001330	DIODE,SILICON 1SS133T-77	△ Q501	T410K26470	FET 2SK2647-01MR
D651	D97U06R21B	DIODE,ZENER MTZJ6.2B T-77	△ Q502	TCAT032034	TRANSISTOR,SILICON KTC3203_Y-AT
D652	0021E3Q030	LED LTL-1CHAE-002A	Q503	TCATC31980	TRANSISTOR,SILICON KTC3198-AT(Y,GR)
D657	D97U06R21B	DIODE,ZENER MTZJ6.2B T-77	Q504	TAAT012714	TRANSISTOR,SILICON KTA1271_Y-AT
D659	D97U06R21B	DIODE,ZENER MTZJ6.2B T-77	△ Q505	TDA0016910	TRANSISTOR,SILICON KTD1691Y
D681	0021E5Q210	LED LTL-1CHGE-002A	△ Q506	TAAT012714	TRANSISTOR,SILICON KTA1271_Y-AT
D1701	D2WXXN40050	DIODE,SILICON 1N4005-EIC	Q651	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D1702	D2WXXN40050	DIODE,SILICON 1N4005-EIC	Q652	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D1703	D28T21DQ09	DIODE,SCHOTTKY 21DQ09N-TA2B1	Q701	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D1704	D28T21DQ09	DIODE,SCHOTTKY 21DQ09N-TA2B1	Q702	TPYJA05001	COMPOUND TRANSISTOR DTA143EKAT146
D1705	D97U09R11B	DIODE,ZENER MTZJ9.1B T-77	Q703	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D1707	D97U05R11B	DIODE,ZENER MTZJ9.1B T-77	Q704	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D1708	D97U09R11B	DIODE,ZENER MTZJ9.1B T-77	△ Q1701	TDA0016910	TRANSISTOR,SILICON KTD1691Y
D1709	D1VT001330	DIODE,SILICON 1SS133T-77	△ Q1703	TCAT03209Y	TRANSISTOR,SILICON KTC3209_Y-AT
D3001	0010E00330	INFRARED LED LTE-3271T-012A-O	△ Q1704	TAAT01281Y	TRANSISTOR,SILICON KTA1281_Y
D3007	D1VT001330	DIODE,SILICON 1SS133T-77	Q1707	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D3009	D1VT001330	DIODE,SILICON 1SS133T-77	△ Q1708	TCAT03209Y	TRANSISTOR,SILICON KTC3209_Y-AT
D8003	D97U06R21B	DIODE,ZENER MTZJ6.2B T-77	△ Q1709	TCAT032034	TRANSISTOR,SILICON KTC3203_Y-AT
D8004	D97U06R21B	DIODE,ZENER MTZJ6.2B T-77	Q1710	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
D8009	D97U06R21B	DIODE,ZENER MTZJ6.2B T-77	△ Q1711	TAAT01281Y	TRANSISTOR,SILICON KTA1281_Y
D8010	D97U06R21B	DIODE,ZENER MTZJ6.2B T-77			

ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
TRANSISTORS			COILS & TRANSFORMERS		
Q1712	TNYJC05001	COMPOUND TRANSISTOR	DTC124EKAT146	L8003	02167F101J COIL 100 UH
Q1713	TPYJC05001	COMPOUND TRANSISTOR	DTA124EKAT146	L8005	02167F100J COIL 10 UH
Q1714	TPYJC05001	COMPOUND TRANSISTOR	DTA124EKAT146	L8006	021LA61R0M COIL 1 UH or
Q3001	0002700690	PHOTO COUPLER	RPI-303		0216A61R0K COIL 1 UH
Q3002	0002700690	PHOTO COUPLER	RPI-303	L8007	021LA6100J COIL 10 UH or
Q3003	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK		0216A6100K COIL 10 UH
Q3004	0002700680	PHOTO COUPLER	RPI-352C40N	L8008	02167F101J COIL 100 UH
Q3005	0002700680	PHOTO COUPLER	RPI-352C40N	L8009	02167F101J COIL 100 UH
Q3006	0000M00390	PHOTO TRANSISTOR	ST-304L	L8010	02167F101J COIL 100 UH
Q3007	TPYJA05001	COMPOUND TRANSISTOR	DTA143EKAT146	L8301	02167F101J COIL 100 UH
Q3008	0000M00390	PHOTO TRANSISTOR	ST-304L	L8302	02167F101J COIL 100 UH
Q8004	TNYJC05001	COMPOUND TRANSISTOR	DTC124EKAT146	L8303	02167F101J COIL 100 UH
Q8005	TNYJC05001	COMPOUND TRANSISTOR	DTC124EKAT146	L8501	0216S74R7J COIL 4.7 UH
Q8008	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK	Δ T501	0481291224 TRANSFORMER,SWITCHING 81291224
Q8011	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK	JACKS	
Q8012	TNYJC05001	COMPOUND TRANSISTOR	DTC124EKAT146	J651	060J421039 RCA JACK MSP-281V31-A
Q8013	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK	J652	060J401098 RCA JACK MSP-281V40-B
Q8015	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK	J653	060J401099 RCA JACK MSP-281V42-B
Q8301	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK	J654	063D700010 JACK MDC-012V1-A_LF or
Q8302	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK		063D700007 JACK MDC-012V1-A
Q8303	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK	J8001	063D000077 SOCKET,21PIN MRC-021V-27_PC
Q8304	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK	J8002	060J411033 RCA JACK MSP-213V1-732_NI_LF
Q8305	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK	SWITCHES	
Q8306	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK	SW651	0504101T34 SWITCH,TACT EVQ21505R
Q8307	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK	SW652	0504101T34 SWITCH,TACT EVQ21505R
Q8308	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK	SW653	0504101T34 SWITCH,TACT EVQ21505R
Q8309	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK	SW681	0504R01T38 SWITCH,TACT EVQ11L05R
Q8310	TPYJC05001	COMPOUND TRANSISTOR	DTA124EKAT146	SW682	0504R01T38 SWITCH,TACT EVQ11L05R
Q8311	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK	SW683	0504R01T38 SWITCH,TACT EVQ11L05R
Q8312	TPYJC05001	COMPOUND TRANSISTOR	DTA124EKAT146	SW684	0504R01T38 SWITCH,TACT EVQ11L05R
COILS & TRANSFORMERS			SW685	0504R01T38 SWITCH,TACT EVQ11L05R	
L101	02167F101J	COIL 100 UH	SW686	0504R01T38 SWITCH,TACT EVQ11L05R	
L102	031616003R	COIL,BIAS OSC 1616003	SW687	0504R01T38 SWITCH,TACT EVQ11L05R	
L103	02167F101J	COIL 100 UH	SW688	0504R01T38 SWITCH,TACT EVQ11L05R	
L104	02167F101J	COIL 100 UH	SW3001	0508S11001 SWITCH (LEAF) LSA-1144EAU	
L106	021LA6820K	COIL 82 UH	P.C.BOARD ASSEMBLIES		
L107	021LA6820K	COIL 82 UH	or	PCB010	A2D501T010 PCB ASS'Y VMD329A
	0216A6820K	COIL 82 UH		PCB240	A2D501T240 PCB ASS'Y VPC174A
L108	02167F220J	COIL 22 UH		PCB270	A2D501T270 PCB ASS'Y VECA30A
L109	021LA6120J	COIL 12 UH	or	PCBB10	A2D501TB10 PCB ASS'Y VMD334A
	0216A6120K	COIL 12 UH		MISCELLANEOUS	
L110	021LA6390J	COIL 39 UH	or	B501	024HT03563 CORE,BEADS W4BRH3.5X6X1.0X2
	0216A6390K	COIL 39 UH		B4001	024HC31022 CORE,BEADS FCM2012H-102T04
L111	02167F101J	COIL 100 UH		B4002	024HC31022 CORE,BEADS FCM2012H-102T04
L112	02167F220J	COIL 22 UH		B4003	024HC31022 CORE,BEADS FCM2012H-102T04
L113	021LA61R0M	COIL 1 UH		B7301	024HC31022 CORE,BEADS FCM2012H-102T04
L114	021LA61R0M	COIL 1 UH		B7302	024HC31022 CORE,BEADS FCM2012H-102T04
L115	021LA61R0M	COIL 1 UH		B7303	024HC36001 CORE,BEADS HCB2012K-600T25
L301	02167F101J	COIL 100 UH		B7304	024HC36001 CORE,BEADS HCB2012K-600T25
Δ L501	029T000108	COIL,LINE FILTER 0R5A393F24		B7305	024HC36001 CORE,BEADS HCB2012K-600T25
L502	02AHB0A0A4	CORE,FERRITE W5T_20*10*10A		B7306	024HC36001 CORE,BEADS HCB2012K-600T25
L503	02167E100K	COIL 10 UH		B7307	024HC36001 CORE,BEADS HCB2012K-600T25
L504	02167F100J	COIL 10 UH		B8001	024HC31022 CORE,BEADS FCM2012H-102T04
L506	021W7A220K	COIL 22 UH	or	B8501	024HC31022 CORE,BEADS FCM2012H-102T04
	02167E220K	COIL 22 UH		B8502	024HC31022 CORE,BEADS FCM2012H-102T04
L507	02167E100K	COIL 10 UH		BT601	1412004008 BATTERY,MANGAN R03(AB)E_2P_G
L601	02AHB9A972	CORE,FERRITE W5T29X7.5X19		CD102	122F061501 CORD,JUMPER 2F061501
L651	021LA6101J	COIL 100 UH	or	Δ CD501	1206459804 CORD,AC BUSH 6459804
	0216A6101K	COIL 100 UH		CD502	WPL6028038 FLAT CABLE AWM2468 AWG26 16C BLACK 280MM
L701	02167F220J	COIL 22 UH		CD504	06CU641201 CORD,CONNECTOR CU641201
L702	02167F220J	COIL 22 UH		CD601	06CDVA5003 CABLE,21PIN S-1002B
L703	02167F220J	COIL 22 UH		CD651	06CU252802 CORD,CONNECTOR CU252802
L801	02167F220J	COIL 22 UH		CP101	0697290620 CONNECTOR PCB SIDE TOC-C09X-A1
L802	02167F220J	COIL 22 UH		CP102	069J760599 CONNECTOR PCB SIDE IMSA-9604S-06C
L803	02167F220J	COIL 22 UH		CP103	067U002019 WIRE HOLDER B2013H02-2P
L1702	02167F470J	COIL 47 UH		CP502	067U016019 WIRE HOLDER B2013H02-16P
L1703	021W7A220K	COIL 22 UH	or	CP504	069V140339 CONNECTOR PCB SIDE A2544WV2-4P
	02167E220K	COIL 22 UH		CP506	069S220629 CONNECTOR PCB SIDE A2001WV2-2P
L3002	02167F220J	COIL 22 UH		CP651	069S250639 CONNECTOR PCB SIDE A2001WR2-5P
L3003	021LA6120J	COIL 12 UH	or	CP681	069S250639 CONNECTOR PCB SIDE A2001WR2-5P
	0216A6120K	COIL 12 UH		CD4003	06CUJB1401 CORD,CONNECTOR CUJB1401
L7302	0216S71R0J	COIL 1 UH		CD6002	06CDL02002 RF CABLE PAL FTZ CDL02002
L7303	0216S71R0J	COIL 1 UH		CD7301	122H0K1802 CORD,JUMPER 2H0K1802
L7305	0216S71R0J	COIL 1 UH		CD7302	122H0K1802 CORD,JUMPER 2H0K1802
L7306	0216S71R0J	COIL 1 UH		CD7303	122H0I1802 CORD,JUMPER 2H0I1802
L8001	02167F220J	COIL 22 UH		CD7304	06CU2A3701 CORD,CONNECTOR CU2A3701
L8002	02167F220J	COIL 22 UH		CP1701	069R2G0589 CONNECTOR PCB SIDE 52147-1610

ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION
MISCELLANEOUS		
CP1703	069S2A0629	CONNECTOR PCB SIDE A2001WV2-10P
CP3001	06972C0010	CONNECTOR PCB SIDE TMC-J12P-B2
CP4006	06A9604010	CONNECTOR PCB SIDE PHA204-2002A01A
CP4007	069S270639	CONNECTOR PCB SIDE A2001WR2-7P
CP7301	069EVKT040	CONNECTOR PCB SIDE 04_6232_120_103_800
CP7302	069EVKT040	CONNECTOR PCB SIDE 04_6232_120_103_800
CP7303	069EVIT040	CONNECTOR PCB SIDE 04_6232_118_103_800
CP7304	069S2A0629	CONNECTOR PCB SIDE A2001WV2-10P
CP8301	069JVK0200	CONNECTOR PCB SIDE IMSA-9615S-20C-PP-A
CP8302	069JVK0200	CONNECTOR PCB SIDE IMSA-9615S-20C-PP-A
CP8303	069JVI0200	CONNECTOR PCB SIDE IMSA-9615S-18C-PP-A
Δ DK4001	169V00027A	DECK CD DVR-106OR
DISC601	1474111002	DVD-RW DISC DVD-RW47EB
EL2402	124120301A	EYE LET XRY20X30BD
Δ F501	080NT04004	FUSE 50T040H
FH501	06710T0006	HOLDER,FUSE EYF-52BC
FH502	06710T0006	HOLDER,FUSE EYF-52BC
Δ ICP501	0835C01003	MICRO FUSE 20N_1000FS
Δ ICP1702	0835C01603	MICRO FUSE 20N_1600FS
Δ M501	1519X56L03	FAN MOTOR 2410ML-04W-B10-C47
NR4001	110N4470M3	R,NETWORK CAY16-470-J-4R
NR4002	110N4470M3	R,NETWORK CAY16-470-J-4R
NR4003	110N4470M3	R,NETWORK CAY16-470-J-4R
NR4004	110N4470M3	R,NETWORK CAY16-470-J-4R
NR4005	110N4470M3	R,NETWORK CAY16-470-J-4R
NR4006	110N4470M3	R,NETWORK CAY16-470-J-4R
NR4007	110N4470M3	R,NETWORK CAY16-470-J-4R
NR4008	110N4470M3	R,NETWORK CAY16-470-J-4R
NR4009	110N4220M3	R,NETWORK CAY16-220-J-4R
NR4010	110N4220M3	R,NETWORK CAY16-220-J-4R
NR4011	110N4472M3	R,NETWORK CAY16-472-J-4R
NR4012	110N4472M3	R,NETWORK CAY16-472-J-4R
NR4015	110N4472M3	R,NETWORK CAY16-472-J-4R
NR8501	110N4220M3	R,NETWORK CAY16-220-J-4R
NR8502	110N4220M3	R,NETWORK CAY16-220-J-4R
NR8507	110N4000M3	R,NETWORK CAY16-000-J-4R
NR8508	110N4000M3	R,NETWORK CAY16-000-J-4R
OS651	077Q037009	REMOTE RECEIVER PIC-37043LO-H
TM601	076R0J020	TRANSMITTER R25-2097
Δ TU301	0162K01033	RF UNIT TCMK0601PD20D
V651	096F90R404	TUBE FLUORSCENT DISPLAY HNV-09SS48
X101	100DT4R410	CRYSTAL AT-49
X301	1002A0R503	CERAMIC OSCILLATOR CSB500E5
X801	100CT01803	CRYSTAL HC-49/U-S
X3001	100CT01002	CRYSTAL HC-49/U-S
X3002	100DA32R01	CRYSTAL DT-26
X3003	100CT01701	CRYSTAL HC-49/U-S
X4001	100WT02707	CRYSTAL FXO-31FL
X8501	100CT03203	CRYSTAL CX-49G

RESISTOR

RC..... CARBON RESISTOR

CAPACITORS

CC..... CERAMIC CAPACITOR
 CE..... ALUMI ELECTROLYTIC CAPACITOR
 CP..... POLYESTER CAPACITOR
 CPP..... POLYPROPYLENE CAPACITOR
 CPL..... PLASTIC CAPACITOR
 CMP..... METAL POLYESTER CAPACITOR
 CMPL..... METAL PLASTIC CAPACITOR
 CMPP..... METAL POLYPROPYLENE CAPACITOR